Southmedic 1983

The KOOS GOWN®

by KOOS MEDICAL INNOVATIONS

The new standard in Infection Prevention



Preferred by Healthcare Professionals

The KOOS GOWN™ is a no-tie, no-gap isolation gown engineered for full coverage, even in motion. Easy to put on and remove, it's the gown healthcare workers want to wear.

Driven by insight and built on purpose, this is where bold thinking meets thoughtful execution.

Part ID	Description	Stock UM
SMI1/KG-2-XL-001	Koos Gown, XL, 100/cs	100/CS
SMI1/KG-2-XXL-001	Koos Gown, XXL, 100/cs	100/CS

No Ties, No Hassle

Streamlined design makes gowning faster & easier

Closes the Coverage Gap

Raised neck helps reduce gaping and exposure

Designed to Support Compliance

Physician - Designed with infection control in mind





To DONN the Gown

1-SHAKE OUT



Hold gown by the shoulders and shake gently to fully unfold. Ensure the neck opening hangs down in front.

2-INSERT ARMS



Slide arms into the sleeves, inserting thumbs through the thumb holes.

3-PULL GOWN OVER HEAD



Pull the gown over your head and down to cover your torso.

4-SECURE THE NECK



Wrap the neck piece from the left side around the back of your neck.
Secure the adhesive tab on the right side.

5-SECURE THE WAIST



COMPLETE



To DOFF the Gown



Release
Lift off neck & waist adhesive tabs.

Drop
Let attachments hang down.

Remove
Follow CDC front-doffing guidelines



CAUTION: When Doffing, pull only the gown body. Do not pull on the neck or waist attachments.

Southmedic Inc.
50 Alliance Blvd.,
Barrie, ON Canada L4M 5K3
www.southmedic.com

email: custserv@southmedic.com
1-800-463-7146 *Toll free in North America*
1-705-720-1902
1-705-728-9537 *Fax*